

## **Front View**

# Universally programmable master module



## **Features**

- Programming of 200 function blocks, such as PI controllers, timing elements, etc.
- Programming with the software Visulink Designer
- 4-line, blue-lit plain text display with 8-button control panel
- Connection of a maximum of 16 field modules
- Connection to the Wurm system over a CAN-bus connection and Frigodata XP



## Note!

• The main module HVL-G3 is only supported by Frigodata XP.



## Writing conventions

Symbol	Meaning	
⚠ CAUTION!	Avoid the described hazard: Otherwise minor or medium bodily injury or property damage will result.	
Avoid the described hazard: Otherwise there is danger from electric voltation that can lead to death or serious bodily injury.		

#### For your safety

For safe operation and to avoid personal injury and equipment damage through operational error, always read these instructions, become familiar with the device, and implement all of the safety instructions on the product and in these instructions as well as the safety guidelines of Wurm GmbH & Co. KG Elektronische Systeme. Keep these instructions ready to hand for quick reference and pass them on with the device when the product is sold.

Wurm GmbH & Co. KG Elektronische Systeme accepts no liability in case of improper use or use for other than the intended purpose.

Target group	These instructions are intended for "service technician" personnel.	
Intended purpose	ended purpose The HVL-G3 is a universally programmable main module.	



#### **WARNING!**

#### Danger of death from electric shock!

- Switch off the power to the entire system when installing, wiring or removing! Otherwise a mains voltage may still be present even if the control voltage is switched off!
- The wiring of the device should be carried out only by a qualified electrician!
- Use only the correct tools for all work!
- Check all wiring after connection!
- Never expose the device to moisture, for example due to condensation or cleaning agents!
- Take the device out of operation if it is faulty or damaged and is therefore compromising safe operation!



#### **CAUTION!**

## Danger of fire if there is overloading of the connections!

Ensure the maximum loads on all connections!

#### Faults are caused by electromagnetic interference!

Use only shielded data lines and place them far away from power lines!

#### Damage to device if handled incorrectly!

- Do not open the device.
- Do not repair the device yourself! If required, send it in for repair with an exact description of the fault!


## Software revisions and validity of documentation

Software version		Functional upgrade	Page
2012-04	V7.2	Basis of documentation	

Any software versions not listed are special solutions for individual projects and are not documented in detail in this description. This document automatically ceases to be valid if a new technical description is issued. Manufacturer: Wurm GmbH & Co. KG Elektronische Systeme. For further information, see our website at <a href="https://www.wurm.de">www.wurm.de</a>



## Circuit diagram



## Montage



## WARNING! Danger of death from electric shock!

 Switch off the power to the entire system before installing! Otherwise, external voltage can be present even when control voltage is shut off.



Installation in the MGR



Installation with ZEM

### Installation in the mounting frame MGR130/140

Push the device in the mounting frame to the stop until it locks between the spring clips.



#### Note!


 Please observe the product information for the MGR130/140 module frame.

# Individual installation with screw clamps of the ZEM type

Insert the device up to the stop in a section of a switching cabinet door. Then fix the device with screw clamps of the ZEM type to the switching cabinet door.




# **Product information**



Installation section for individual installation

## Wiring and connection of several main modules



Technical data				
Supply voltage	230V~, +10% / -15%, 50Hz., max. 13VA			
Displays	<ul> <li>4-line clear text display with background lighting</li> <li>4 x yellow LED menu selection</li> <li>1 x red LED, flashing in case of fault</li> <li>1 x yellow LED for operating status of communication bus</li> <li>1 x yellow LED for operating status of field bus</li> </ul>			
Field bus	3-wire CAN-bus interface, shielded, electrically isolated Push-in terminals 2.5mm² or RJ-45 socket			
Communication bus	3-wire CAN-bus interface, shielded, electrically isolated Push-in terminals 2.5mm² or RJ-45 socket			
Digital inputs	6 x 24V=, self-supplied, approx. 5mA per input, push-in terminals, 2.5mm <sup>2</sup>			
Digital outputs	8 x closing contact with common supply, 1A, rated voltage 230V~, push-in terminals 2.5mm²			
Dimensions	(WxHxD) 109 x 109 x 92mm			
Front plate	Plastic, foil			
Mounting	In the module frame / individual mounting			
Ambient temperature	0+50°C operation / -25+70°C storage			
Weight	About 650g			
CE conformity	EC conformity according to - 2004/108/EC (EMC Directive) - 2006/95/EC (Low Voltage Directive)			
	RoHS			
Valid from	Version 7.0			